

# SAFETY INSTRUCTIONS

**Important when cutting stone products, the following safety precautions must always be followed.**

1. Ensure the equipment being used is done so in accordance with the manufacturer's instructions.
2. Always wear approved safety glasses when cutting stone products.
3. An Australian / New Zealand Standard 1716 approved respirator should be worn if airborne dust is generated. The minimum being a disposable P1 respirator.
4. Hearing protection equipment should be worn when cutting stone.
5. Clear the cutting area of any off cut pieces prior to activating saw.
6. Adopt safe working practices at all times, ensuring no unprotected persons are in the immediate vicinity.
7. All cutting should be carried out externally ensuring ant nearby windows and/or doors remain closed whilst cutting.
8. Wet cutting should be used to suppress airborne dust, the debris should be collected before it dries out and disposed of appropriately.
9. Where wet methods are not available or practical exhaust ventilation, with the hood positioned near the point of cutting, should be used. High efficiency particulate (HEPA) filter fitted vacuum cleaner should also be considered for collecting dry debris, otherwise dry debris should be collected with damp rags not by using a broom or brush.

**Resellers of DécoR Stone products have a legal responsibility to make sure clients are aware of these safety requirements.**

---

## CONTACT DETAILS:

DécoR Stone

84-90 Highbury Road Burwood VIC 3125

PH: (03) 9888 9888

F: (03) 9888 9884

W: [www.decorstone.com.au](http://www.decorstone.com.au)

E: [sales@decorstone.com.au](mailto:sales@decorstone.com.au)

# DÉCOR CRAZY PAVING

## APPLICATION INSTRUCTIONS FOR CRAZY PAVING

<b>SOURCE</b>	China	<b>SIZE</b>	Approximately 500mm x 500mm
---------------	-------	-------------	-----------------------------

### COLOURS

1. Sahara - Off White/ Beige
2. Charcoal - Dark Grey
3. Bisque - Sandy/ Orange
4. Russet - Deep Red/ Brown

DécoR Crazy Paving comes in interlocking tiles of approximately 500mm x 500mm and are sold in lots of 4 (1 lot being considered 1m<sup>2</sup>).

1. Make sure surface is clean and dry.
2. Apply selected tile adhesive as per manufacturers' instructions in accordance with current weather conditions.
3. Use angle grinder to cut any tiles along edges as required.
4. Lay DécoR Crazy Pave so as to provide a snug fit into previous laid sheets allowing for a uniform gap between sheets.
5. Apply a coat of Dura Slate Gloss Sealer prior to grouting. Allow to dry for 24 hours.
6. Mix up selected grouting material and apply as per manufacturers instructions and clean off excess from slate tiles.
7. Apply a minimum of 1 coat of Dura Slate Gloss sealer for a deeper "wet look" after grouting has set for 24 hours.

### CONTACT DETAILS:

DécoR Stone  
84-90 Highbury Road Burwood VIC 3125  
**PH:** (03) 9888 9888      **F:** (03) 9888 9884  
**W:** [www.decorstone.com.au](http://www.decorstone.com.au)      **E:** [sales@decorstone.com.au](mailto:sales@decorstone.com.au)