

Application Instructions for Décor Crazy Paving

Source:	China
Colours:	1. Sahara - Off White/ beige 2. Charcoal - Dark Grey 3. Bisque - Deep red/orange 4. Russet- - Deep red/brown
Size:	600mm x 600mm

Décor Crazy Pave comes in interlocking tiles of approximately 600mm x 600mm and are sold in lots of 4 (1 lot being considered 1m2)

Technical Instructions for installing Décor Crazy Paving.

1. Make sure surface is clean and dry
2. Apply selected tile adhesive as per manufacturers' instructions in accordance with current weather conditions.
3. Use angle grinder to cut any tiles along edges as required.
4. Lay Décor Crazy Pave so as to provide a snug fit into previous laid sheets allowing for a uniform gap between sheets.
5. Allow to dry for 24 hours
6. Mix up selected grouting material and apply as per manufacturers instructions and clean off excess from slate tiles.
7. Apply a minimum of 2 coats of Dura Slate Gloss sealer for a deeper "wet look" or a minimum of 2 coats of DuraSlate Finish/ Primer to retain the lighter natural look.
8. A coat of Duraslate Gloss can be applied over the Finish/Primer for increased protection from wear.

::: showroom :::
84-90 Highbury Road Burwood
Victoria
telephone: (03) 9888 9888
facsimile: (03) 9888 9884
email: sales@decorstone.com.au